

Change of Raw Material Supplier for HogoMax102-10 Additive

Thank you for your continued use of DISCO products.
The details regarding the change are as follows.

Introduction

This Technical Newsletter serves as a notice regarding a change in the raw material supplier for the HogoMax102-10 additive.

There is no change regarding the following:

- Manufacturing method and quality control of HogoMax102-10
- HogoMax102-10 specification sheet
- Part number of HogoMax102-10

We appreciate your understanding and cooperation.

Background

DISCO was contacted by the supplier that produces the additive, which is one of the raw materials used in HogoMax102-10, and received news that production will be discontinued. Therefore, DISCO made the decision to change to a new raw material supplier.

Applicable Product

Product name	Volume (L)	Dilution ratio	Part No.
HogoMax102-10	20	1.0	KS14-102021-0
	5		KS14-100521-0

Components and Content of HogoMax102-10

The applicable raw material is the “additive” displayed in the list below.

There is no change in the component name and content (%) of the additive.

Component names	Content (%)
Propylene glycol monomethyl ether	10–20
Polyvinyl alcohol	10–20
Additive	5–15
Methanol	<0.3
Water	Remaining content

Technical Newsletter

#TNL2022-0002 e (2/2)



Evaluation Results

Three lots of HogoMax102-10 were produced using the product manufactured by the new raw material supplier of the additive, and it was confirmed that there is no difference in product quality.

HogoMax102-10

Inspection item	Standard value	Unit	Lot 1	Lot 2	Lot 3
Viscosity	46.0–56.0	mPa·s	50.0	53.2	50.7
Content of metallic purities	Na: <50	ppb	6	9	3
	K: <50		1	0	0
	Fe: <50		1	1	1
	Cu: <50		0	0	0
Color	0.000–0.060 (absorption at a wavelength of 420 nm)	—	0.029	0.027	0.021

Changeover Period

This change will be applied sequentially to lots delivered from June 1, 2022 onwards.

Please note that the existing product may be shipped even after the abovementioned period for inventory-related reasons.

Other Points to be Noted

- 1) Based on the notice through this technical newsletter, it shall be assumed that all customers have consented to this change.
- 2) If you require product samples of the new HogoMax102-10 for evaluation, please contact a DISCO sales representative and let them know the amount required.

Inquiries

If you have any questions or concerns, please contact a DISCO sales representative.

End of document